



BAMBOO GESTURE GUIDE

USING TOUCH WITH THE BAMBOO PAD





Wacom products that support touch are designed to enhance the way you work.

Touch enables you to interact with a computer using only your fingertips on your Bamboo pad.

In the illustrations below:


- A filled gray circle indicates a tap and hold.
- An unfilled circle indicates a tap to click.
- A filled circle with a black outline indicates a tap, then a tap and hold.

BASIC FUNCTIONS

MOVE SCREEN CURSOR	Touch and slide a single finger across the pad surface.
ADD TAP TO CLICK 	Move your cursor to an item. Tap with your thumb or a second finger to the left. <ul style="list-style-type: none"> • If the pad orientation is set for left-handed use, touch to the right of the primary finger. • This gesture requires driver installation.
ADD TAP TO RIGHT CLICK (Mac only) 	Move your cursor to an item. Tap with a second finger to the right. <ul style="list-style-type: none"> • If the pad orientation is set for left-handed use, touch to the left of the primary finger. • This gesture requires driver installation.




SWIPE FROM RIGHT EDGE TO OPEN CHARMS
(Windows 8 only)




Swipe with one finger from the right edge of the pad toward the center to open Charms.

SWIPE FROM LEFT EDGE TO SWITCH APPS
(Windows 8 only)




Swipe with one finger from the left edge of the pad toward the center to switch between open applications.

SWIPE FROM TOP OR BOTTOM EDGE TO OPEN
APP BAR (Windows 8 only)




Swipe with one finger from the top or bottom edge of the pad toward the center to open the application bar.

SWIPE FROM TOP EDGE OVER BOTTOM EDGE
TO CLOSE APP (Windows 8 only)



Swipe with one finger from above the top edge of the pad over the bottom edge to close an application.

SCROLL




Move two fingers smoothly together in parallel.







- Move up to scroll up.
- Move down to scroll down.
- Move left to scroll left.
- Move right to scroll right.


Natural Scrolling in Mac OS 10.7 and 10.8: For Natural Scrolling, refer to your Mac usage or support documentation.

TAP TO RIGHT CLICK




Tap with two fingers spaced slightly apart.

<p>ZOOM</p> 	<p>Expand two fingers away from each other to zoom in. Pinch two fingers together to zoom out.</p>
<p>ROTATE</p> 	<p>Move two fingers clockwise or counter-clockwise.</p> <ul style="list-style-type: none"> This gesture requires driver installation.
<p>SMART ZOOM (Mac only)</p> 	<p>Double-tap with two fingers to zoom in. Double-tap a second time to zoom out.</p>
<p>SWIPE FROM RIGHT EDGE TO OPEN NOTIFICATION CENTER (Mac OS 10.8 only)</p> 	<p>Swipe with two fingers from the right edge of the pad toward the center to open the Notification Center.</p>
<p>SWIPE LEFT/RIGHT TO NAVIGATE</p> 	<p>Swipe with two or three fingers spaced slightly apart.</p> <ul style="list-style-type: none"> Swipe right to send a 'Forward' command in most browsers and picture viewers. Swipe left to send a 'Back' command.
<p>SWIPE UP TO SHOW DESKTOP</p> 	<ul style="list-style-type: none"> Swipe up using three fingers to show the desktop on Windows. You can use four fingers if the driver has been installed. Swipe up using four fingers to show the desktop on Mac. Swipe up again to move your open windows back to the desktop. <u>Mac OS 10.7</u>: Swipe up for Mission Control. Swipe up again to exit Mission Control.


SWIPE DOWN FOR WINDOWS START


Swipe down with three fingers spaced slightly apart.

- This gesture does not require driver installation.


DOUBLE TAP FOR LOOK UP (Mac OS 10.8 only)


Tap twice with three fingers spaced slightly apart.

DRAG



Use three fingers spaced slightly apart.

Mac OS 10.7 only: Tap to select. Lift your finger from the pad surface.

SWIPE LEFT/RIGHT TO SWITCH APPLICATIONS


Swipe left or right using four fingers spaced slightly apart to open the application switcher.

Mac OS 10.7: Swipe left or right to switch between full-screen apps.

SWIPE DOWN FOR FLIP 3D/EXPOSÉ/ APP EXPOSÉ/



Swipe down using four fingers.

- Windows: Swipe down for Flip 3D. This gesture requires driver installation.
- Exposé (Mac): Swipe once to open Exposé. Swipe down again to close Exposé.
- App Exposé, Mac 10.7 and 10.8: Swipe down to preview the open windows of the app you are working with. Swipe down again to exit App Exposé.

PINCH FOR LAUNCHPAD


Mac OS 10.7 and 10.8: Pinch your thumb and three fingers together to fade your open windows and display all of your apps.

EXPAND TO SHOW DESKTOP



Mac OS 10.7 and 10.8: Expand your thumb and three fingers apart.

Bamboo Gesture Guide

Using touch with the Bamboo pad

Version 1.0, Rev H2014

Copyright © Wacom Co., Ltd., 2014

All rights reserved. No part of this document may be reproduced except for your express personal use. Wacom reserves the right to revise this publication without obligation to provide notification of such changes. Wacom does its best to provide current and accurate information in this document. However, Wacom reserves the right to change any specifications and product configurations at its discretion, without prior notice and without obligation to include such changes in this document.

Bamboo and Wacom are registered trademarks of Wacom Co., Ltd.

Microsoft and Windows are either registered trademarks or trademarks of Microsoft Corporation in the United States and/or other countries. Apple and Mac are trademarks of Apple, Inc., registered in the U.S. and other countries.

Any additional company and product names mentioned in this documentation may be trademarked and/or registered as trademarks. Mention of third-party products is for informational purposes only and constitutes neither an endorsement nor a recommendation. Wacom assumes no responsibility with regard to the performance or use of these products.